



Profit from the Eagle Advantage®

Cooper Medical Ltd

Ph: 0800 800 823

Email: admin@coopermedical.co.nz

Specification Sheet

Short Form Specifications

Eagle Stem Caster Cart, model _____ (EAGLEbrite®, Chrome) four-shelf cart with patented QuadTruss® design open-grid wire shelves, 63" posts, donut bumpers and casters. 68" overall height. Unit shipped knocked down.



Options / Accessories

- Ledges
- Dividers
- Shelf markers
- Tray slides
- Rods & tabs
- Utility drawer

Stem Caster Carts

MODELS:

- | | | |
|-----------------------------------|-----------------------------------|-----------------------------------|
| <input type="checkbox"/> CC1836-* | <input type="checkbox"/> CC2136-* | <input type="checkbox"/> CC2436-* |
| <input type="checkbox"/> CC1848-* | <input type="checkbox"/> CC2148-* | <input type="checkbox"/> CC2448-* |
| <input type="checkbox"/> CC1860-* | <input type="checkbox"/> CC2160-* | <input type="checkbox"/> CC2460-* |

* See chart on back for complete model numbers.

Design and Construction Features

- Sturdy, mobile four-shelf carts available in mirror chrome and EAGLEbrite® zinc finishes.
- Patented QuadTruss® design (patent #5,390,803) makes shelves up to 25% stronger and provides a retaining ledge for increased storage stability and product retention.
- Open-wire construction promotes higher visibility by allowing light to pass through the shelves, permits greater air circulation which helps reduce dust and contamination build up, and increases the effectiveness of fire suppression systems.
- 63" (1600mm) posts are numbered on vertical one inch increments to help ensure fast and level assembly. Shelving can be adjusted up and down every inch for optimum cart configuration.
- Fast assembly without tools: Numerically calibrated grooved posts, tapered high temperature resistant plastic split sleeves and shelf collars combine to make shelving assembly a simple two-step exercise:
 - 1) Snap the split sleeves onto the posts at the location of your choice;
 - 2) Slide the collars of the shelf over the split sleeves.
 A positive lock between the shelf and the split sleeves is created without the use of any tools, becoming stronger as additional weight is added to the shelving.
- Variety of 5" (127mm)-diameter, 1¼" (32mm)-wide casters available.
- 68" (1727mm) overall height.
- Shipped knocked-down.

Distributed in New Zealand by:



Cooper Medical Limited
57 Mahunga Drive
Mangere Bridge
Auckland 2022

Certifications / Approvals



AUTOQUOTES



EG01.07 Rev. 08/11



Profit from the Eagle Advantage®

Item No.: _____
 Project No.: _____
 S.I.S. No.: _____

Stem Caster Carts

EAGLEbrite® model #	chrome model #	shelf dimensions		weight lbs.	weight kg	caster type	wheel tread		
		width in.	width mm					length in.	length mm
CC1836Z-S	CC1836C-S	18"	457	36"	914	58	26.3	swivel	resilient
CC1836Z-SP	CC1836C-SP	18"	457	36"	914	58	26.3	swivel	poly
CC1836Z-SB	CC1836C-SB	18"	457	36"	914	58	26.3	swivel/brake	resilient
CC1836Z-SBP	CC1836C-SBP	18"	457	36"	914	58	26.3	swivel/brake	poly
CC1836Z-SR	CC1836C-SR	18"	457	36"	914	58	26.3	swivel/rigid	resilient
CC1836Z-SRP	CC1836C-SRP	18"	457	36"	914	58	26.3	swivel/rigid	poly
CC1848Z-S	CC1848C-S	18"	457	48"	1219	70	31.7	swivel	resilient
CC1848Z-SP	CC1848C-SP	18"	457	48"	1219	70	31.7	swivel	poly
CC1848Z-SB	CC1848C-SB	18"	457	48"	1219	70	31.7	swivel/brake	resilient
CC1848Z-SBP	CC1848C-SBP	18"	457	48"	1219	70	31.7	swivel/brake	poly
CC1848Z-SR	CC1848C-SR	18"	457	48"	1219	70	31.7	swivel/rigid	resilient
CC1848Z-SRP	CC1848C-SRP	18"	457	48"	1219	70	31.7	swivel/rigid	poly
CC1860Z-S	CC1860C-S	18"	457	60"	1524	86	39.0	swivel	resilient
CC1860Z-SP	CC1860C-SP	18"	457	60"	1524	86	39.0	swivel	poly
CC1860Z-SB	CC1860C-SB	18"	457	60"	1524	86	39.0	swivel/brake	resilient
CC1860Z-SBP	CC1860C-SBP	18"	457	60"	1524	86	39.0	swivel/brake	poly
CC1860Z-SR	CC1860C-SR	18"	457	60"	1524	86	39.0	swivel/rigid	resilient
CC1860Z-SRP	CC1860C-SRP	18"	457	60"	1524	86	39.0	swivel/rigid	poly
CC2136Z-S	CC2136C-S	21"	533	36"	914	67	30.4	swivel	resilient
CC2136Z-SP	CC2136C-SP	21"	533	36"	914	67	30.4	swivel	poly
CC2136Z-SB	CC2136C-SB	21"	533	36"	914	67	30.4	swivel/brake	resilient
CC2136Z-SBP	CC2136C-SBP	21"	533	36"	914	67	30.4	swivel/brake	poly
CC2136Z-SR	CC2136C-SR	21"	533	36"	914	67	30.4	swivel/rigid	resilient
CC2136Z-SRP	CC2136C-SRP	21"	533	36"	914	67	30.4	swivel/rigid	poly
CC2148Z-S	CC2148C-S	21"	533	48"	1219	79	35.8	swivel	resilient
CC2148Z-SP	CC2148C-SP	21"	533	48"	1219	79	35.8	swivel	poly
CC2148Z-SB	CC2148C-SB	21"	533	48"	1219	79	35.8	swivel/brake	resilient
CC2148Z-SBP	CC2148C-SBP	21"	533	48"	1219	79	35.8	swivel/brake	poly
CC2148Z-SR	CC2148C-SR	21"	533	48"	1219	79	35.8	swivel/rigid	resilient
CC2148Z-SRP	CC2148C-SRP	21"	533	48"	1219	79	35.8	swivel/rigid	poly
CC2160Z-S	CC2160C-S	21"	533	60"	1524	96	43.5	swivel	resilient
CC2160Z-SP	CC2160C-SP	21"	533	60"	1524	96	43.5	swivel	poly
CC2160Z-SB	CC2160C-SB	21"	533	60"	1524	96	43.5	swivel/brake	resilient
CC2160Z-SBP	CC2160C-SBP	21"	533	60"	1524	96	43.5	swivel/brake	poly
CC2160Z-SR	CC2160C-SR	21"	533	60"	1524	96	43.5	swivel/rigid	resilient
CC2160Z-SRP	CC2160C-SRP	21"	533	60"	1524	96	43.5	swivel/rigid	poly
CC2436Z-S	CC2436C-S	24"	610	36"	914	74	33.5	swivel	resilient
CC2436Z-SP	CC2436C-SP	24"	610	36"	914	74	33.5	swivel	poly
CC2436Z-SB	CC2436C-SB	24"	610	36"	914	74	33.5	swivel/brake	resilient
CC2436Z-SBP	CC2436C-SBP	24"	610	36"	914	74	33.5	swivel/brake	poly
CC2436Z-SR	CC2436C-SR	24"	610	36"	914	74	33.5	swivel/rigid	resilient
CC2436Z-SRP	CC2436C-SRP	24"	610	36"	914	74	33.5	swivel/rigid	poly
CC2448Z-S	CC2448C-S	24"	610	48"	1219	90	40.8	swivel	resilient
CC2448Z-SP	CC2448C-SP	24"	610	48"	1219	90	40.8	swivel	poly
CC2448Z-SB	CC2448C-SB	24"	610	48"	1219	90	40.8	swivel/brake	resilient
CC2448Z-SBP	CC2448C-SBP	24"	610	48"	1219	90	40.8	swivel/brake	poly
CC2448Z-SR	CC2448C-SR	24"	610	48"	1219	90	40.8	swivel/rigid	resilient
CC2448Z-SRP	CC2448C-SRP	24"	610	48"	1219	90	40.8	swivel/rigid	poly
CC2460Z-S	CC2460C-S	24"	610	60"	1524	110	49.9	swivel	resilient
CC2460Z-SP	CC2460C-SP	24"	610	60"	1524	110	49.9	swivel	poly
CC2460Z-SB	CC2460C-SB	24"	610	60"	1524	110	49.9	swivel/brake	resilient
CC2460Z-SBP	CC2460C-SBP	24"	610	60"	1524	110	49.9	swivel/brake	poly
CC2460Z-SR	CC2460C-SR	24"	610	60"	1524	110	49.9	swivel/rigid	resilient
CC2460Z-SRP	CC2460C-SRP	24"	610	60"	1524	110	49.9	swivel/rigid	poly

EAGLE GROUP
 100 Industrial Boulevard, Clayton, DE 19938-8903 USA
 Phone: 302-653-3000 • Fax: 302-653-2065
 www.eaglegrp.com

Foodservice Division: Phone 800-441-8440
 MHC/Retail Display Divisions: Phone 800-637-5100

Printed in U.S.A.
 ©2011 by Eagle Group

Rev. 08/11

Spec sheets available for viewing, printing or downloading from our online literature library at www.eaglegrp.com

Although every attempt has been made to ensure the accuracy of the information provided, we cannot be held responsible for typographical or printing errors. Information and specifications are subject to change without notice. Please confirm at time of order.